

# CROSSIS

## Installation instructions for kick scooters - series CROSS

### Step 1.



Make sure that carton is not damaged

### Step 2.



Remove the kick scooter out of the box

### Step 3.



Remove the tape holding front and rear wheel

### Step 4.



Remove the protecting material from frame

### Step 5.



Remove the protecting material from handlebars

### Step 6.



Put wheels aside

### Step 7.



Loosen the screws on the stem and align so that it faces forward while riding

### Step 8.



In this step set the direction of the stem roughly. You will align it precisely later with the wheel on

### Step 9.



Tighten the screws on the stem with force 4 NM

### Step 10.



Remove the screws from the front part of the stem

### Step 11.



Attach the handlebars

### Step 12.



Put back the front part of the stem and lightly tighten, adjust the angle of the handlebar and screw it with 4 NM





Remove the plastic stopper from between the brake pads. **ATTENTION! DO NOT PRESS BRAKE LEVER UNTIL YOU PUT THE WHEEL BACK ON!**



Put from wheel back on, tighten quick release. Mind the direction of the wheel



Correct position of the quick release axle to the fork after tightening



Stem and front wheel must form a single axis. Make sure that stem is properly tightened with force 4 NM



Check the slope of the handlebars so it will suit the angle of the brake levers. We recommend setting at 45 degrees



We wish you many happy kilometers on your new kick scooter CRUSSIS!